



Programming Diagnostics

MASERATI

RSA-MAS1

- 1x **RED** = No high speed CAN activity. Check CAN wires.
- 2x **RED** = Keyless codes not learned, be sure to press the unlock button on the OEM keyfob.
- 3x **RED** = No PTS on received (no 12V). Check PTS connection.
- 4x **RED** = No data on the immobilizer. Check if there is another OEM keyfob in the vehicle, then check immobilizer data wire connection.
- 5x **RED** = Ignition never turns ON. Check ignition wire connection.
- 6x **RED** = VIN not found. Check the CAN connections.
- 7x **RED** = No PTS off received (no GND). Check PTS connection.
- 8x **RED** = No PTS on (no 12V). Check PTS connection.
- 9x **RED** = No data on the immobilizer. Check if there is another OEM keyfob in the vehicle, then check immobilizer data wire connection.
- 10x **RED** = Not the same key! Use only ONE key for module programming.
- 11x **RED** = No data on the immobilizer. Check if there is another OEM keyfob in the vehicle, then check immobilizer data wire connection.
- 12x **RED** = No push received (no 12V). Check PTS connection.
- 13x **RED** = No data on the immobilizer. Check if there is another OEM keyfob in the vehicle, then check immobilizer data wire connection.
- 14x **RED** = No data on the immobilizer. Immobilizer data wire connection is on the wrong side of the cut or bad internal relay.
- 15x **RED** = Klon is invalid. Redo part 2 of Klon.

