

BlackVue Cloud Viewer – Interface Guide

Adjust language, file location, map speed unit, map service

Create an account, check usage, change password, logout

Access help, terms of use, latest news from BlackVue, all notifications

About BlackVue Cloud Viewer

Click to start or end Live View

Your BlackVue account

Switch between your dashcam's location and the publicly shared cameras map

Click X to close the current file and return to the map

- Double-click a camera to start Live View.
- Right-click a camera to modify camera settings, view camera info, change camera name or unregister a camera.

Playback screen

Register a BlackVue dashcam to your account

Select to view files in the BlackVue, Cloud Storage, or Local Disk.

* Click '.' to change the Local Disk file storage location.

Filter files by direction and recording mode:

- : Front
- : Rear
- : Normal
- : Parking
- : Event
- : Manual

Click to turn on/off the voice communication feature.

Map screen

Recorded file list

- Double-click a file to play.
- Right-click a file to copy to local disk or copy to the cloud.

Fit to playback screen

Flip horizontally

Flip upside-down

View full screen

Camera settings

Right-click on your camera in **My camera(s)** and select **Camera settings** to open the settings window.

