



Model: AC100GPS

GPS TRACKING, FLEET MANAGEMENT **& DRIVER COACHING**

View the location of your vehicle or fleet of vehicles in real-time from your Smartphone or any connected device. Know exactly where family members or fleet drivers are and where they've been from anywhere at any time.

Replay where they've stopped, idled, entered or exited a specified landmark, or even breached an after-hours driving policy. Manage speeding, aggressive driving and ensure your vehicles are well maintained with service reminders.



COVERT INSTALL Hardwired behind dash installation



LANDMARKS

Set virtual perimeters; be notified of entries and exits



BACKUP BATTERY Worry-free battery disconnected operation



Review driving history and see times and routes taken



ACCELEROMETER Detects aggressive driving and unwanted movement



ALERTS Receive alerts via text or email for any activity



AUTOCONNECT

STEALTH SERVICE PLANS



GPS FEATURESIndexIndexIndexIndexIndexIndexAuto Position Updating20 Min*20 Min*5 Min*3 Min*1 Min*Unlimited On Demand Locates•••••••Starter Disable On / Off•••••••••Voltage Request••• <t< th=""><th>AIRTIME PLANS</th><th>Gps</th><th>Gps+</th><th>Auto Track 5</th><th>Auto Track 3</th><th>Auto Track 1</th></t<>	AIRTIME PLANS	Gps	Gps+	Auto Track 5	Auto Track 3	Auto Track 1
Unlimited On Demand LocatesImage: Constraint of the second se	GPS FEATURES					
Starter Disable On / OffImage: Construct of the starter of the startero	Auto Position Updating		20 Min*	5 Min*	3 Min*	1Min*
Voltage Request••••Low Battery Warning w/Disconnect Alert••••Programmable Input / Output••••Vehicle Tow Alerts••••Landmark Entrance / Exit Alerts••••Geofence Breach Alert••••Service Reminder (Virtual Odometer)••••After hours Usage Detection••••Over-speed Alert•••••Excessive Idling•••••Driver Coaching Beeper•••••Acceleration / Hard Braking Alerts•••••Reporting: Asset by Location••••••Reporting: Excessive Idling by Location•••••Reporting: Service & Maintenance•••••	Unlimited On Demand Locates	•	•	•	•	•
Low Battery Warning w/Disconnect AlertImage: Constraint of the second of th	Starter Disable On / Off	•	•	•	•	•
Programmable Input / OutputImage: Constraint of the second se	Voltage Request	•	•	•	•	•
Vehicle Tow AlertsImage: Constraint of the second seco	Low Battery Warning w/Disconnect Alert	•	•	•	•	•
Landmark Entrance / Exit AlertsImage: Construct of the second	Programmable Input / Output	•	•	•	•	•
Geofence Breach Alert••	Vehicle Tow Alerts	•	•	•	•	•
Service Reminder (Virtual Odometer)Image: Constraint of the service Reminder (Virtual Odometer)Image: Constraint of the service Reminder (Virtual Odometer)After hours Usage DetectionImage: Constraint of the service Reminder (Virtual Odometer)Image: Constraint of the service (Virtual Odometer)Image: Const	Landmark Entrance / Exit Alerts	•	•	•	•	•
After hours Usage Detection•••••Over-speed Alert•••••••Excessive Idling••••••••••Driver Coaching Beeper···••	Geofence Breach Alert	•	•	•	•	•
Over-speed Alert••••Excessive Idling•••••Driver Coaching Beeper•••••Acceleration / Hard Braking Alerts•••••Reporting: Asset by Location•••••Reporting: Over-speed by Location•••••Reporting: Excessive Idling by Location•••••Reporting: Service & Maintenance•••••	Service Reminder (Virtual Odometer)	•	•	•	•	•
Excessive IdlingImage: Service & MaintenanceImage:	After hours Usage Detection	•	•	•	•	•
Driver Coaching Beeper Image: Constraint of the second	Over-speed Alert	•	•	•	•	•
Acceleration / Hard Braking AlertsImage: Constraint of the second se	Excessive Idling		•	•	•	•
REPORTS Reporting: Asset by Location ●	Driver Coaching Beeper			•	•	•
Reporting: Asset by Location ● <td< td=""><td>Acceleration / Hard Braking Alerts</td><td></td><td></td><td>•</td><td>•</td><td>•</td></td<>	Acceleration / Hard Braking Alerts			•	•	•
Reporting: Over-speed by Location • • • • Reporting: Excessive Idling by Location • • • • Reporting: Service & Maintenance • • • •	REPORTS					
Reporting: Excessive Idling by Location • • • Reporting: Service & Maintenance • • •	Reporting: Asset by Location	•	•	•	•	•
Reporting: Service & Maintenance	Reporting: Over-speed by Location	•	•	•	•	•
	Reporting: Excessive Idling by Location		•	•	•	•
Reporting: Overview by Vehicle	Reporting: Service & Maintenance			•	•	•
	Reporting: Overview by Vehicle			•	•	•

*Reporting frequency when ignition is on.





REAL-TIME GPS TRACKING

View the real-time location and driving history of your vehicle or vehicle fleet from your Smartphone or any connected device.

On demand location tracking Landmark entrance/exit monitoring Excessive idling and speed monitoring After hours usage detection



ADVANCED AUTOTRACK REPORTING

Record the position and status of your vehicle or vehicle fleet automatically as it moves on Google Maps with AutoTrack service plans.

Live tracking Reports each stop position Arrival and departure times Historical replay tool



LOCATION SECURITY MONITORING

Take comfort in knowing that your vehicle or vehicle fleet is being monitored 24/7. Set triggered alerts that you have authorized by text message or email notification.

Tow alert Geofence breach alert Location exit/entrance alert After hours usage alert

