



Programming Diagnostics

ACURA / HONDA

HA

No diagnostic codes available. Contact technical support.

HA1

No diagnostic codes available. Contact technical support.

HA2

No diagnostic codes available. Contact technical support.

HA3

1x **RED** = No CAN activity in the last 2 seconds. Check CAN wire connections.

HA4

1x **RED** = No CAN activity in the last 2 seconds. Check CAN wire connections.

HA5

No diagnostic codes available. Contact technical support.

HA6

1x **RED** = No CAN activity. Check the CAN wire connections.
2x **RED** = Klon data is wrong! Check the immobilizer data wire connection. Also try opening and closing driver door.
3x **RED** = No immobilizer data. Check the immobilizer data wire connection.
4x **RED** = VIN not found. Check CAN wire connections or flash by vehicle.

HA7

1x **RED** = No CAN activity. Check the CAN wire connections.
2x **RED** = Klon data is wrong! Check the immobilizer data wire connection. Also try opening and closing driver door.
3x **RED** = No immobilizer data. Check the immobilizer data wire connection.
4x **RED** = VIN not found. Check CAN wire connections or flash by vehicle.

