


01 [4x]
WARNING: Complete the module programming procedure and tach programming procedure before programming the remotes. A maximum of four [4x] remotes per system.



02 Set ignition to ON position.



03 Press and release the antenna button, then press and hold the antenna button. The antenna's leds will turn solid BLUE.




04 Parking Light will flash once [1x].




05 Press once [1x] on the LOCK button of each remote.



06 The antenna's leds will flash BLUE once [1x] for each successful pairing.



07 Release the antenna button. The antenna's leds will turn OFF.



08 Set ignition to OFF position.



09 Remote Programming Procedure completed.



>> To program an additional remote as second vehicle mode: Follow steps 1 to 4. Press twice [2x] on the "F" button then press once [1x] on the LOCK button of the remote. Follow steps 6 to 9.

