


Drone with EVO-ONE

Flash the EVO-ONE **Remote Starter** side to 0.50.

Reorganize the DRONE connector PINOUT as shown.



Connect the DRONE in the EVO-ONE **BLUE** Connector with clip as shown.

